




## ASSEMBLY INSTRUCTIONS M183 (PT-033-NC)

### EN - To unfold

ES-Para desplegar / FR-Déplier / DE-Zum Ausklappen / IT-Aprire / PT-Para desdobrar / CA- Per desplegar / NL-Uitklappen / PO-ROZŁOŻENIE / RO-Extindere / BG-За разгъване / HU-Kinyitni  
 EL-Για να ανοίξετε / TR-Açmak için / ع-الفتح / TH- 展開 / RU-Разложить / SV-Fäll upp / DA-Udklaping / NO-Brette ut / CS-Rozložit / SR-Da se rasklopi / HR-Rasklopiti / JA-広げる。  
 ZH- 展开 / LT-Išskleisti / SK-Pre rozloženie / לקפל - HE




**PUSH**



### EN - To fold

ES-Para plegar / FR-Plier / DE-Zum Einklappen / IT-Piegare / PT-Para dobrar / CA-Per plegar / NL-Inklappen / PO-ZłOŻENIE / RO-Pliere / BG-За събиране / HU-Összecsuni /  
 EL-Για να κλείσετε / TR-Katlamak için / ع-اللفح / TH- 折叠 / RU-Сложить / SV-Fäll ihop / DA-Sammenklaping / NO-Brette sammen / CS-Složít / SR-Da se sklopi / HR-Sklopiti /  
 JA-折りたたむ。/ ZH- 折叠 / LT-Suskleisti / SK-Pre zloženie / לקטוע / HE



**PUSH**

